


## How to Update firmware

Step 1 Open the web browser and type the IP address of the device in the address bar (default is 192.168.169.1). Press Enter.




Step 2 Type the username and password in the login page, the default username and password both are admin, click OK to log into the device.



**Note: Please do remember to pull out the data card before perform the next step.**

Step 3: Click "settings" > Admin > upload", choosing the software version which is preserved in your hard disk in advance that you want to update.



Step4: Do remember: after updating, it should be loaded factory defaults by configuring software or by hand. Two ways' effect are the same.

1) Click "settings" > Admin > "settings", then choose the "Load Factory Defaults" in this interface.

**Settings Management**

You might save system settings by exporting them to a configuration file, restore them by importing the file, or reset them to factory default

Export Settings	
Export Button	Export

Export LOG	
Debug Switch	open close
Export Button	Export

Import Settings	
Settings file location	选择文件 未选择文件
	Import Cancel

Load Factory Defaults	
Load Default Button	Load Default

2) Pressing the reset button of router by using acicular article for more than 5s. The 2G/3G led light is Blue flashing when you load factory defaults.

